




Stitching: Model CHESS, sofa,
210 x 95 cm in leather, #7420020




Stitching: Model CHESS, sofa,
230 x 95 cm in leather, #7430030




Stitching: Model CHESS, corner section,
95 x 95 cm in leather, #7609595




Stitching: Model CHESS, corner section,
L-95 x R-115 cm / L-115 x R-95 cm in leather, #7609511 / 7601159




Stitching: Model CHESS, closing section, right and left,
135 x 95 cm in leather, #744-135 / #745-135




Stitching: Model CHESS, closing section, right and left,
175 x 95 cm in leather, #744-175 / #745-175




Stitching: Model CHESS, closing section, right and left,
210 x 95 cm in leather, #744-210 / #745-210



Stitching: Model CHESS, closing section, right and left,
135 x 115 cm in leather, #754-135 / #755-135



Stitching: Model CHESS, chaiselong, right and left,
100 x 155 cm in leather, #7580000 / #7590000



Stitching: Model CHESS, footstool,
100 x 60 cm in leather, #7350000

