


# How to remove the removable frame cover

Model Baseline



- push the steel bar, which is placed in the slit between the back and the seat, downwards away from the seat, until it is free of the two hooks, and remove it from the sofa.



- pull the elastic string, which is placed in the slit between the armrest and the seat, release it from the hooks in both ends, and remove it from the sofa.



- take carefully the removable cover off.