



Model Bench · Design by Nils Juul Eilersen


Total depth (frame): 15 3/4" · Seat height: 15 3/4" and 18"



Bench with Ø0.5" buttons
47 1/4" x 15 3/4"



Bench without buttons
47 1/4" x 15 3/4"



Bench with Ø0.5" buttons
55" x 15 3/4"



Bench without buttons
55" x 15 3/4"



Bench with Ø0.5" buttons
63" x 15 3/4"



Bench without buttons
63" x 15 3/4"



Bench with Ø0.5" buttons
70 3/4" x 15 3/4"



Bench without buttons
70 3/4" x 15 3/4"



Bench with Ø0.5" buttons
47 1/4" x 15 3/4"




Bench without buttons
47 1/4" x 15 3/4"



Bench with Ø0.5" buttons
55" x 15 3/4"



Bench without buttons
55" x 15 3/4"



Bench with Ø0.5" buttons
63" x 15 3/4"



Bench without buttons
63" x 15 3/4"



Bench with Ø0.5" buttons
70 3/4" x 15 3/4"



Bench without buttons
70 3/4" x 15 3/4"



Model Bench · Design by Nils Juul Eilersen

Total depth (frame): 15 3/4" · Seat height: 15 3/4" and 18"



Bench with Ø0.5" buttons
47 1/4" x 15 3/4"




Bench without buttons
47 1/4" x 15 3/4"



Bench with Ø0.5" buttons
55" x 15 3/4"



Bench without buttons
55" x 15 3/4"



Bench with Ø0.5" buttons
63" x 15 3/4"



Bench without buttons
63" x 15 3/4"



Bench with Ø0.5" buttons
70 3/4" x 15 3/4"




Bench without buttons
70 3/4" x 15 3/4"



Bench with Ø0.5" buttons
47 1/4" x 15 3/4"




Bench without buttons
47 1/4" x 15 3/4"




Bench with Ø0.5" buttons
55" x 15 3/4"




Bench without buttons
55" x 15 3/4"



Bench with Ø0.5" buttons
63" x 15 3/4"



Bench without buttons
63" x 15 3/4"



Bench with Ø0.5" buttons
70 3/4" x 15 3/4"



Bench without buttons
70 3/4" x 15 3/4"

Scale 1:100
All overall dimensions correspond to frame sizes.
The drawings are not a detailed expression of how the final furniture appears.